



天吊り用 マウント取付ネジ M4  
The screw which attaches a projector to a ceiling