

■ 制御・管理  
◆ RS232C プロトコル

Function	Protocol Name	Command								Response							
<b>Setting Group</b>																	
Volume	VVL	#	V	V	L	:	PARAM:0 to 20	CR	=	V	V	L	:	PARAM:0 to 20	CR		
Picture Mode	PIC	#	P	I	C	:	PARAM : 0 to 2	CR	=	P	I	C	:	PARAM : 0 to 2	CR		
Picture Mode 1 = 0 (Bright)		#	P	I	C	:	'0'	CR	=	P	I	C	:	'0'	CR		
Picture Mode 2 = 1 (Standard)		#	P	I	C	:	'1'	CR	=	P	I	C	:	'1'	CR		
Picture Mode 3 = 2 (Natural)		#	P	I	C	:	'2'	CR	=	P	I	C	:	'2'	CR		
<b>Execution Group</b>																	
Turn On Standby > ON	PON	#	P	O	N	:			=	P	O	N	:	'S'	'C'	ID	CR
Turn Off ON > Standby	POF	#	P	O	F	:			=	P	O	F	:	'S'	'C'	ID	CR
<b>Toggle Function Group</b>																	
AV Mute	MUT	#	M	U	T	:	PARAM : 0 to 1	CR	=	M	U	T	:	PARAM : 0 to 1	CR		
AV Mute On = 1		#	M	U	T	:	'1'	CR	=	M	U	T	:	'1'	CR		
AV Mute Off = 0		#	M	U	T	:	'0'	CR	=	M	U	T	:	'0'	CR		
<b>Source Group</b>																	
Input Source	INP	#	I	N	P	:	PARAM : 0 to 13	CR	=	I	N	P	:	PARAM : 0 to 13	CR		
RGB 1 = 3		#	I	N	P	:	'3'	CR	=	I	N	P	:	'3'	CR		
RGB 2 = 5		#	I	N	P	:	'5'	CR	=	I	N	P	:	'5'	CR		
HDMI = 6		#	I	N	P	:	'6'	CR	=	I	N	P	:	'6'	CR		
HDMI2 = 7		#	I	N	P	:	'7'	CR	=	I	N	P	:	'7'	CR		
Video = 9		#	I	N	P	:	'9'	CR	=	I	N	P	:	'9'	CR		
S-Video = 10		#	I	N	P	:	'1'	'0'	CR	=	I	N	P	:	'1'	'0'	CR
<b>Projector Status Group</b>																	
Projector Power State	SPS	#	S	P	S	:			=	S	P	S	:	PARAM : 0 to 7	CR		
Input Source Information	SIS	#	S	I	S	:			=	S	I	S	:	PARAM : 0 to 255	CR		
Detected Error Type	SER	#	S	E	R	:			=	S	E	R	:	PARAM : 0 to 255	CR		
User Lamp Time	SLT	#	S	L	T	:			=	S	L	T	:	*Note U1	CR		
Total Time	STT	#	S	T	T	:			=	S	T	T	:	*Note U1	CR		
Software Version	SSV	#	S	S	V	:			=	S	S	V	:	4Byte ASCII Code	CR		